

PRODUCT INFORMATION:

Read this information before proceeding. It is the user's responsibility to take the following precautions at all times.

- Always stake or weigh down your Z-Shade™ product. Do not use in any potentially windy or rainy weather. Wind and rain can damage your product and may also result in injury to you or others. Therefore, do not rely on product for protection in heavy or prolonged rain storms.
- The Z-Shade product is designed as a temporary sun shelter. Do not leave up for extended periods.
- Use caution when handling the Z-Shade frame. Avoid pinching hands or fingers as frame opens or closes.
- Do not use Z-Shade product in a lightning storm.
- Do not leave your Z-Shade product unattended.
- Do not build fires under Z-Shade product.
- DO NOT USE FOR VEHICLE STORAGE.

PRODUCT CARE/MAINTENANCE:

For long lasting durability and the best possible protection for your Z-Shade product, follow these care and maintenance instructions:

- Use a mild soap (not detergent) and plenty of water for top cleaning.
- Let the Z-Shade top and frame dry completely before closing or storing to avoid mildew.
- The Z-Shade frame will operate and look better if occasionally wiped with silicone spray, especially before and after use in damp conditions. Remove excess silicone residue before attaching top.
- Slightly tighten bolts if frame becomes loose.

1 YEAR LIMITED WARRANTY

Z-Shade Company Ltd., manufacturer of the product, warrants to the original purchaser who provides a dated sales receipt from an Authorized Dealer, each part of the Z-Shade product to be free from defects in material or workmanship for a period of one (1) years after the date of original purchase. The Z-Shade frame is covered under a limited one (1) year warranty and guarantees the frame to be free from defects in material or workmanship. This warranty applies only for normal and expected uses, as determined by the manufacturer.

Z-Shade Company Ltd. obligation and liability under this warranty is limited to the repair or replacement (*at its option*) of the product or its parts, after its own review and examination.

RETURN GOODS: Before returning any part or product to Z-Shade, please phone or write to obtain specific return shipping instructions. All shipping costs must be prepaid, and Z-Shade is not responsible for products damaged in transit.

CONDITIONS: This warranty shall be void as to any product which has been altered or modified in any manner. This warranty does not apply to damages caused by wind, rain, or other forces of nature, not to accidental or deliberate damage of the product, nor to use of the product that does not conform with the product instructions.

This warranty is provided in lieu of all other warranties, expressed or implied.

©2014 Z-Shade Company Ltd. All Rights Reserved.

EVEREST 1214

USER MANUAL



EVEREST

Instant CANOPY

10ft. x 20ft.
(3.05m x 6.1m)



Z-Shade Company Ltd.

(855) 4 Z-SHADE

(855) 497-4233

www.zshadeusa.com






PACKAGE INCLUDES

- Z-Shade Frame
- 4-Piece Stake Kit
- Canopy Top
- Storage Bag



INITIAL SET UP

Please read each step before you attempt to set up. Save these instructions for future reference.




Locking Strips





- 1 With partner, grasp two outer legs, slightly lift off the ground, and step backwards – stopping at full arms' length - approximately 3/4 its total size.
- 2 Unfold the canopy top and place it over the open frame. – Align the four corners of the top over the corners of the frame.
- 3 Secure the canopy top to the frame by attaching the locking strips on the top with the locking strips on the frame. Pull the corners down fully.

SET UP

- 1 With partner on opposite side of canopy, place your Z-Shade frame in the center of area to be shaded. Grasp outer legs, lift off the ground, and step backwards - stopping at full arms' length.






- 2 Grasp the top and bottom of the truss on opposite sides. Slightly lift canopy up and push hands together while stepping backwards until canopy is fully opened. Be careful not to pinch fingers or push too hard so as to avoid damage to truss.





- 3 Engage Pull Pin slider at each corner by pushing up on slider with one hand while holding down on top of leg with other hand. Pull Pin will engage in hole. Repeat on opposite legs.
- 4 With partner, lift outer legs up and slide out the inner legs until the snap button locks into outer legs. Repeat on opposite legs.
 - 4a Lower adjacent center leg until snap button locks. Repeat on opposite center leg

TAKE DOWN



- 1 With partner, raise & slightly lift up center legs, depress snap button to unlock and telescope inner legs into outer legs. Repeat on opposite center leg. – With partner, lift up canopy outer legs and depress snap button to unlock and telescope inner legs into outer legs. Repeat on opposite legs.
- 2 Release Pull Pin at each corner by first lifting fabric away from slider. With one hand push up on truss near the Pull Pin, pull the pin out to release. **Note:** It is much easier to release Pull Pin when the canopy weight has been removed from the Pull Pin.



- 3 Grasp top and bottom of truss. Slightly lift the canopy up and shake while stepping towards your partner until 3/4 closed.
- 4 With partner on opposite side, grasp 2 outer legs, push frame together to slightly and shake it while stepping towards your partner until fully closed. **Be careful not to pinch fingers!** Store canopy in storage bag.

WARNING: Keep all flame and heat sources away from all product fabrics. These fabrics meet the flammability requirements of CPAI-84. The fabric may burn if left in continuous contact with any flame source. The application of any foreign substance to the fabric may render the flame-resistant properties ineffective. DO NOT USE AS CARPORT/VEHICLE PROTECTION.